


# P0550 Save A Drop™ Water Meter



(E) Everytime watering volume

(W) Watering volume accumulation

Your Digital Water Flow Meter comes to you with the battery already installed.

**Button A:** 1) Resets the top counter (E) to zero

**Button B:** 1) Resets the bottom counter (W) to zero

The LCD displays will flash once after inserting a new battery, then screen appears as above.  
The default measurement is LIT (Litres)

**Battery save mode:** The screen will fade out in 30 minutes if there is no water flow or no button activation  
Also the interval measurement will reset to zero.

**To start the counting function from the battery save mode:**

- 1) Press button A or B (or both A & B)
- 2) The device will detect any water flow and start to count.

## Operation

- 1) When water flow commences, both (E) and (W) will count the flow volume (fig 1).
- 2) To zero (E) reading, press button A. (fig 2).
- 3) (W) reading continues to accumulate water volume (fig 3) until zeroed
- 4) To take both (E) and (W) back to zero press button B.

## How to switch measurement (Litre/Gallon)

Press button A for three seconds and release. A black dot will flash in the lower left corner (fig 4).

Select GAL or LIT by pressing the button. B Then press button A to confirm the setting

In this mode, the flow meter counter will revert to the counting function in 30 seconds if no button is pressed.




fig1




fig 2




fig 3




fig 4