## INSTRUCTIONS



# RECHARGEABLE GREEN LED WORKLIGHT/FLASHLIGHT









# INSTRUCTIONS

## WHAT'S IN THE BOX

- Active Eye Rechargeable Green LED Worklight/Flashlight
- Micro USB charging cable
- Instructions

## FEATURES

- Two green LED lights—a bright 5W Worklight and a 3W Flashlight.
- Adjustable pivoting head tilts up to 180°, so you can focus light where you need it.
- Strong 360° rotatable swivel hook lets you hang your light anywhere.
- Powerful base magnets let you stick the light to almost any metal surface.



SPECIFICATIONS				
BULB TYPE	BATTERY TYPE	CHARGING TIME	WORKING TIME	INPUT
Worklight: 5W COB LED	3.7V 18650 Li-ion battery 4000 mAh	About 4 hours	Worklight: About 4 hours	Micro USB
Flashlight: 3W LED			Flashlight: About 4 hours	

# 

- We recommend that you fully charge the battery before use.
- Recharge the battery before it is fully discharged. The green battery power display shows the remaining battery power.
- Disconnect from the USB cable when the battery is fully charged.
- Keep the battery away from extreme temperatures, especially heat.
- DO NOT attempt to open the battery compartment.

## **BEFORE YOU BEGIN**

The unit comes 80–90% charged so you can use it right away. However, for best results we recommend that you fully charge the battery before your first use.

### Charging the Battery

Connect the unit to a power source using the included Micro USB cable.

#### **Battery Power Display**

Each light in the green power display represents 25% of battery power.

Flashing: The battery is charging.

All four lights are ON: The battery is fully charged.

**USING THE LIGHT** 

(I) ON/OFF: The On/Off button cycles through three options: Flashlight on, Worklight on, both lights off.

- Press once to turn on • the Flashlight.
- Press again to turn on the Worklight (the Flashlight turns off).
- Press again to turn off the light.



(-) MINUS: Press and hold the Minus button to decrease light intensity.

(+) PLUS: Press and hold the Plus button to increase light intensity.

## **POWER BANK FUNCTION**

When fully charged, the light can be used as a power bank (e.g., to recharge a mobile phone). Simply use your own charging cable to connect your mobile device to the light.



USB **input** to charge the battery is located to the left of the Worklight.





USB output to use light as a power bank is located to the right of the Worklight.



### LIMITED WARRANTY

Hydrofarm warrants the *AELW2* to be free from defects in materials and workmanship. The warranty term is for 1 year beginning on the date of purchase. Misuse, abuse, or failure to follow instructions is not covered under this warranty. Hydrofarm's warranty liability extends only to the replacement cost of the product. Hydrofarm will not be liable for any consequential, indirect, or incidental damages of any kind, including lost revenues, lost profits, or other losses in connection with the product. Some states do not allow limitation on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you. Hydrofarm will, at our discretion, repair or replace the *AELW2* covered under this warranty if it is returned to the original place of purchase. To request warranty service, please return the *AELW2*, with original sales receipt and original packaging, to your place of purchase. The purchase date is based on your original sales receipt.



